

- Alternate Mounting Info and Ideas

Cleat with Flange "out"

Cleat with Flange "in"



1. No wrong way to mount the kit, only most preferred from our experiences.
2. If included template does not fit your project, mount the top cleats first and then fit the lower cleats to suit the application. **No Worries!**
3. Any location for the 4 cleats that can work will be fine and will carry the load of your Varden.
4. Generally the upper and lower cleats are 20" apart (see pics).
5. Flange in and out locations differ (see pics) but you just don't want cleats to interfere with trays.
6. The above holds true for post mounts and leaning 2x4 mounts against walls too. **Get creative!**



Alternate Varden Configurations

Free-Standing



Post Mounts



Simple A-frames for Single and Double-sided Growing



Leaning 2x4 Frame



Double Kits



Leaning Without Drilling Into Wall

